

Vista-32 RAIDTOOL Installation

RAIDTOOL

RAIDTOOL can be used to manage your NVRAID disc arrays. The following are instructions for manually installing RAIDTOOL in Microsoft Vista.

- (1) Use Windows Explorer to locate the RAIDTOOL files on the "Vista-32 Beta-2" drivers CD. This folder is located under IDE\DRIVERS\RAIDTOOL\RAIDTOOL.
- (2) Highlight all of the files in this folder. All files may be highlighted by pressing <CTRL-A> on your keyboard.
- (3) Copy all of these files to C:\WINDOWS\SYSTEM32 by dragging them into this folder.
- (4) While attempting to copy the first file, a warning message will appear warning you that you will need administrator privileges to perform the copy operation into this system folder. To avoid seeing this message in the future, click the box that says "Repeat my answer each time this occurs (119 times)."
- (5) Click "Continue"
- (6) Another error message will be displayed. Click "Continue" again.
- (7) Find the "RegRaid.bat" file in the C:\WINDOWS\SYSTEM32 folder. Place the mouse over this file, and click the right mouse button.
- (8) Select "Run as administrator"
- (9) When the message box appears indicating success, click "OK"
- (10) Create a shortcut to nvraidservice.exe to your windows startup folder.
 - a. Place the mouse over the Windows Start button.
 - b. Right click, and "Open All Users."
 - c. Double Click "Programs"
 - d. Double Click "Startup"
 - e. Right Click and select "New->Shortcut"
 - f. Press "Continue"
 - g. Press "Continue"
 - h. Press "Browse"
 - i. Located the \WINDOWS\SYSTEM32 folder. Select the "nvraidservice.exe" file. Press "OK"
 - j. Press "Next"
 - k. Press "Finish"
 - l. Press "Continue"
 - m. If an error message occurs, ignore it.
- (11) Create a shortcut to nvraidman.exe to the desktop.
 - a. Clear the desktop of all programs.
 - b. Place the mouse on the desktop and right click to select "New->Shortcut"
 - c. Press "Continue"
 - d. Press "Continue"
 - e. Press "Browse"

- f. Located the \WINDOWS\SYSTEM32 folder. Select the "nvraidservice.exe" file. Press "OK"
 - g. Press "Next"
 - h. Press "Finish"
 - i. Press "Continue"
 - j. If an error message occurs, ignore it.
- (12) NVRAIDMAN must be run as administrator. Right click the NVRAIDMAN shortcut, and select "Run as administrator."